

Parachute Operating Instructions  
(also available online at [www.knoll.com](http://www.knoll.com))



**Seat Height**  
(1-piece or 2-piece models)  
Lift the handle on the right to adjust seat height.



**Forward Tilt**  
(optional on two-piece models)  
Slide the grooved mechanism located under the right side of the chair, forward to activate the forward tilt. Recline slightly to engage the mechanism. To return to normal, slide the lever back to the rear and recline slightly.



**Tension Adjustment**  
(optional on 1-piece models and standard on 2-piece models)  
Lean back and recline. Adjust tension if necessary. Reach under the front of the seat to find the knob. Turn left to tighten and right to loosen.



**Standard Adjustable Arms:**  
(optional)  
**Armpad Height**  
Press the green button on the inside of the arm support for 2 1/2" of height adjustment.



**Tilt Lock**  
(1-piece or 2-piece models)  
On the left side of the chair, pull the lever forward to lock chair upright and push back on the lever to release.



**Arm Width**  
Loosen the three bolts under the arm support with a screwdriver, slide the arm support right or left of center and retighten the bolts for 2" of width adjustment.



**Back Angle Adjustment**  
(2-piece models optional)  
On the right side of the back rest, press the lever outward from the chair to adjust the back angle. There are 6 positions where the back angle can be stopped for total of 15° of adjustability.



**High Performance Arms:**  
(optional)  
**Armpad Height**  
Lift the lever on the outside of the arm support for 3 1/2" of vertical height adjustability.



**Back Height Adjustment**  
(2-piece models only)  
Place both hands on the base of the back and lift to raise the back height. The back height adjusts 5 notches upward for a total of 3" of adjustability. The 6th notch brings the back down to the lowest position.



**Armpad Width**  
Twist the knob located beneath the arm support to adjust the arm supports. Each of the arm supports can be adjusted 2 1/2" in width (1 1/4" each side).



**Armpad Rotation**  
Grasp the armpad at the center and rotate 24° inward.