LRSM Laboratories Infectious Waste Disposal Guide*

* For research laboratories in the School of Arts and Sciences located in the Laboratory for Research on the Structure of Matter (LRSM) (See SEAS waste guide for all SEAS Labs). Procedures may vary in other University spaces. For more information on infectious waste, consult the University's Biological Safety Manual (<u>https://ehrs.upenn.edu/health-safety/biological-safety-manual</u>), or refer questions about the disposal of sharps to EHRS at 215-898-4453 or email the office at <u>ehrs@ehrs.upenn.edu</u>.

Container Type	Glassware/ Plasticware Waste Container	Infectious Waste Sharps Container**	Infectious Waste Autoclave Bags	Infectious Waste Liquid Containers
Contents	Uncontaminated laboratory glassware and plasticware. Chemical bottles must be triple rinsed and label defaced. Trace amounts of chemical contamination is allowed. Line cardboard glassware boxes with heavy, clear plastic liner. Do not use biohazard burn boxes or red/orange bags to collect glass/plasticware waste under any circumstances.	Infectious waste sharps:Infectious waste sharps:or unbroken glass and plasticware that has contacted infectious agents orwas used in animal or human patient care or treatment, including plasticpipettes and other used plasticware that is recognizable after autoclaving ormade of plastic that shatters on breakage or is considered breakable by theinvestigator.Chemical-contaminated sharps waste (trace amounts):Dispose of inReusable Sharps Container -or- segregate into disposable sharps containerslabeled "Chemical Contaminated Sharps Waste – Do Not Autoclave".Non-infectious Sharps (needles, syringes, and blades):Dispose in a sharpscontainer through the infectious waste stream.NOTE: Non-infectious sharps may be commingled with infectious wastesharps or chemical-contaminated sharps waste. If this is done, they must bemanaged as described for the respective category of sharps.	All contaminated laboratory items <u>NOT</u> considered sharps, including used plasticware made of polyethylene (PE), polyvinyl chloride (PVC), and other thermoplastic polymers provided they do not shatter on breakage or are considered unbreakable by the investigator.	Infectious waste fluids (volumes greater than 20 cc).
Reusable	NO	Reusable sharps containers – YES Disposable sharps containers - NO	NO	YES
Disposal Methods	Seal cardboard box when ¾ full for housekeepers to remove. Do not overfill!	<u>Reusable Sharps Containers</u> : are picked up at their location by vendor and replaced with clean containers. <u>Disposable sharps containers</u> : seal and dispose of in reusable sharps container <u>Chemical-contaminated sharps waste and Non-infectious Sharps waste:</u> discard in the sharps container	Seal and discard in the reusable sharps container.	Use appropriate disinfectant before pouring into a sanitary sewer drain. The reusable container must be washed and autoclaved before reuse.
Container Source	User must purchase.	<u>Disposable sharps containers</u> : – user must purchase <u>Reusable containers for sharps</u> : – delivered by vendor: Advant-Edge Solutions (<u>service@asiwaste.com</u>)	User must purchase.	User must purchase.

^{**} NOTE: All sharps must be disposed of in sharps containers at the time of generations and kept there until final destruction. For more details on how to properly sort and manage disposal of all laboratory sharps waste, consult the STANDARD OPERATING PROCEDURE for the DISPOSAL of SHARP OBJECTS in LABORATORIES (<u>https://ehrs.upenn.edu/health-safety/regulated-waste/sharps-glassware/laboratory-sharps-waste</u>).